

How can I pair my SuperTooth Disco with my Bluetooth mobile phone?

Important: Make sure that your Bluetooth mobile phone supports A2DP (Advanced Audio Distribution Profile) before proceeding.

1. From OFF, press and hold the On / Off / Stop button for 5 seconds until beep is heard. The Bluetooth indicator turns blinking red/blue indicating that the SuperTooth Disco is ready to pair.
2. While the SuperTooth Disco is in pairing mode, access the Bluetooth menu of your phone. Turn on its Bluetooth function then execute a Bluetooth search to find the SuperTooth Disco. (See your phone manual).
3. When the phone displays the list of Bluetooth devices, select ST DISCO.
4. When the phone asks for the password / pin code, enter 0000 and press OK.
5. Pairing is successful if the alternating red / blue blinking of the Bluetooth indicator changes to blinking blue (standby mode).

The SuperTooth Disco is now ready to use with your phone.

How can I pair my SuperTooth Disco with my Bluetooth-enabled PC / laptop (or Bluetooth touchpad) or via an USB Bluetooth dongle?

Important: If you use an USB Bluetooth dongle, make sure that your PC or laptop has a Bluetooth dongle that supports A2DP and has A2DP compatible Bluetooth Application software installed before proceeding.

1. From OFF, press and hold the On / Off / Stop button for 5 seconds until beep is heard. The Bluetooth indicator turns blinking red / blue indicating that SuperTooth Disco is ready to pair.
2. While the SuperTooth Disco is in pairing mode, access the Bluetooth program of your PC / laptop / touchpad. Refer to your Bluetooth software manual on how to pair and connect to a device. When computer asks for the password / pin code, enter 0000.
3. If pairing is successful, the Bluetooth indicator turns blinking blue (standby mode) and when connected, the Bluetooth indicator turns steady blue. Depending on the dongle / PC / laptop used, Bluetooth connection will be made automatically or will need to be made manually via the computer menu (see your computer manual).

The SuperTooth Disco is now ready to use with your PC or touchpad.

While listening to the music on the SuperTooth Disco via stereo line input, connected to a MP3 player, a laptop, a touchpad, the sound stops by itself after 20 seconds or 5 minutes even after adjusting the volume on the SuperTooth Disco. What should I do?

The volume level on your MP3 player / laptop / touchpad is too low. Please increase the volume on your MP3 player / laptop / touchpad. Your SuperTooth Disco will now work properly. The suggested volume level of the MP3 player is at 3/4 for optimal working.

While charging my SuperTooth Disco, how do I know when the battery is fully charged?

The Charge indicator at the back of your SuperTooth Disco will turn steady orange while charging. When charging is complete, it will turn steady green.

